



# SUSI Adapters Selection Guide

## New Meters

Select New Meter →

Select Existing Meter being Replaced ↓



Existing GE Series Meters	GE DS-63, DS-65, D66, ES, EV GE KV, KV2, KV2C, M-90				
	SUSI CASE "GS"				
	GE EPM 5100				
	SWRGS_-EPM	SWRGS_-EPM	SWSGS_-EPM	SWDGS_-EPM	
	GE M-90R (Deep GS)				
SUSI Case "GSR"					
GE DS-64					
SUSI Case "GL"					
GE M-90R (Deep "GL")					
SUSI Case "GLR"					

Notes: 1. The “\_” in the SUSI part number is to be replaced with a 5, 6 or 9 for a 2, 2 1/2 and 3 element meters respectively. 600-2010-00-B  
 2. All SUSI SWD series products have the option “-M” for mounting and wiring the meter into the SUSI adapter.



# SUSI Adapters Selection Guide

## New Meters

Select New Meter →

Select Existing Meter being Replaced ↓



Socket Meter

High End Socket Meter

SWB-Ready Socket

Panel Meter

Existing GE Series Meters

GE DS-38  
SUSI # "G38"

GE DS-39  
SUSI # "G39"

GE DS-43  
SUSI # "G43"

GE DS-44  
SUSI Case "GX"

	 SWRG38_	 SWRG38_	 SWSG38	 SWDG38_
	 SWRG399	 SWRG399	 SWSG399	 SWDG399
	 SWRG43_	 SWRG43_	 SWSG43_	 SWDG43_
	 SWRGX_	 SWRGX_	 SWSGX_	 SWDGX

Notes: 1. The “\_” in the SUSI part number is to be replaced with a 5, 6 or 9 for a 2, 2 1/2 and 3 element meters respectively. 600-2010-00-B  
2. All SUSI SWD series products have the option “-M” for mounting and wiring the meter into the SUSI adapter.





# SUSI Adapters Selection Guide

		New Meters			
<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <b>Select New Meter</b> →         </div> <div style="border: 1px solid black; padding: 5px;"> <b>Select Existing Meter being Replaced</b> ↓         </div>		 <p><b>Socket Meter</b></p>	 <p><b>High End Socket Meter</b></p>	 <p><b>SWB-Ready Socket</b></p>	 <p><b>SHARK 200</b> Data-Logging Meter/Transducer</p> <p><b>Panel Meter</b></p>
Existing GE Series Meters	<b>GE DS-53; DS-55 (Semi-Draw-Out)</b>  SUSI case "G53"	 SWRG53_	 SWRG53_	 SWSG53_	 SWDG53_
	<b>GE DS-54 (Semi-drawout)</b>  SUSI case "G54"	 SWRG54_	 SWRG54_	 SWSG54_	 SWDG54
	<b>GE DS-67 (Two 2-element meters); SUSI case "G67"</b>	 Two SWBXS5	 Two SWBXS5	N/A	 SWDG67
	<b>GE DS-69 (Two 2 1/2 element meters); SUSI case "G67"</b>	 Two SWBXS6	 Two SWBXS6	N/A	 SWDG69
	<b>Westinghouse/ABB Series CB, D2B, D4B, D5B, Alpha, L+G 2510, PSI, FT-21 case SUSI case "WS"</b> 	 SWRWS_	 SWRWS_	 SWSWS_	 SWDWS_

Notes: 1. The “\_” in the SUSI part number is to be replaced with a 5, 6 or 9 for a 2, 2 1/2 and 3 element meters respectively. 600-2010-00-B  
 2. All SUSI SWD series products have the option “-M” for mounting and wiring the meter into the SUSI adapter.



# SUSI Adapters Selection Guide

		New Meters			
Select New Meter Select Existing Meter being Replaced		 Socket Meter	 High End Socket Meter	 SWB-Ready Socket	 Panel Meter
Existing Westinghouse/ABB Series Meters	Westinghouse ABB Series CB,D2B, D4B D5B;Alpha, L+G 2510, PSI  FT-32 case SUSI Case "WM"	 SWRWM_	 SWRWM_	 SWSWM_	 SWDWM
	Westinghouse ABB Series CB, D2B, D4B, D5B; Alpha, L+G 2510, PSI  FT-31 case SUSI Case "WL"	 SWRWL_	 SWRWL_	 SWSWL_	 SWDWL
	Westinghouse Series "Old" CB, 2 screws on cover  SUSI "WCB"	 SWAAF_ or SWBXS_	 SWAAF_ or SWBXS_	N/A	 SWDWCB_
	Westinghouse Series D_B-32F Two 2 1/2 element  FT-32 Case SUSI # "W32"	 Two SWBXS6	 Two SWBXS6	N/A	 SWDW32
	Westinghouse Series D_B-38F Two 2 element  FT-32 Case SUSI # "W38"	 Two SWBXS5	 Two SWBXS5	N/A	 SWDW38

Notes: 1. The “\_” in the SUSI part number is to be replaced with a 5, 6 or 9 for a 2, 2 1/2 and 3 element meters respectively.  
 2. All SUSI SWD series products have the option “-M” for mounting and wiring the meter into the SUSI adapter.





# SUSI Adapters Selection Guide

## New Meters

Select New Meter →

Select Existing Meter being Replaced ↓

			
Socket Meter	High End Socket Meter	SWB-Ready Socket	Panel Meter

Existing "Basler" Style Meters

JEM10, JEMSTAR-Trans-data;  
SUSI # "TS"




Schlumberger/Itron, JEM2, Trans-data, Basler Style  
SUSI # "JL"

				
	SWRTS_	SWRTS_	SWSTS_	SWDTS_
				
	SWRJL_	SWRJL_	SWSJL_	SWDJL_

Existing Non-case Meters





PM/GE/Siemens 3700/4700

Cutler Hammer

			N/A	
	SWFXS_	SWFXS_	N/A	SWF3710
			N/A	
	SWBXSL	SWBXSL	N/A	PSISQL

All Others

All other panel meters

			N/A	
	SWAAF_ or SWBXS_	SWAAF_ or SWBXS_	N/A	Various Plates















Notes: 1. The "\_" in the SUSI part number is to be replaced with a 5, 6 or 9 for a 2, 2 1/2 and 3 element meters respectively.  
 2. All SUSI SWD series products have the option "-M" for mounting and wiring the meter into the SUSI adapter. 600-2010-00-B



# SUSI Adapters Selection Guide

## New Installations



<p>New Socket Meter →</p> <p>Select SUSI Adapters Product</p> <p>↓</p>	 <p><b>ION 8500 / 8600</b></p>	 <p><b>GE kv2</b></p>	 <p><b>Itron Sentinel</b></p>	 <p><b>Elster Alpha</b></p>
<p><b>Flush Mount SWAAF_</b></p>				
<p><b>Surface Mount SWBXS_</b></p>				
<p><b>Surface Mount SWFXS_</b></p>				

Notes: 1. The “\_” in the SUSI part number is to be replaced with a 5, 6 or 9 for a 2, 2 1/2 and 3 element meters respectively.  
 2. All SUSI SWD series products have the option “-M” for mounting and wiring the meter into the SUSI adapter.

600-2000-10-B